

# Radio-frequency power generation

*Richard G. Carter*


Engineering Department, Lancaster University, Lancaster LA1 4YR, U.K.  
and The Cockcroft Institute of Accelerator Science and Technology, Daresbury, UK

## Abstract

This paper reviews the main types of radio-frequency power amplifiers which are, or may be, used for high-power hadron accelerators. It covers tetrodes, inductive output tubes, klystrons and magnetrons with power outputs greater than 10 kW continuous wave or 100 kW pulsed at frequencies from 50 MHz to 30 GHz. Factors affecting the satisfactory operation of amplifiers include cooling, matching and protection circuits are discussed. The paper concludes with a summary of the state of the art for the different technologies.

## 1 Introduction

All particle accelerators with energies greater than 20 MeV require high-power radio-frequency (RF) sources [1]. These sources must normally be amplifiers to achieve sufficient frequency and phase stability. The frequencies employed range from about 50 MHz to 30 GHz or higher. Power requirements range from 10 kW to 2 MW or more for continuous sources and up to 150 MW for pulsed sources. Figure 1 shows the main features of a generic RF power system. The function of the power amplifier is to convert d.c. input power into RF output power whose amplitude and phase is determined by the low-level RF input power. The RF amplifier extracts power from high-charge, low-energy electron bunches. The transmission components (couplers, windows, circulators, etc.) convey the RF power from the source to the accelerator, and the accelerating structures use the RF power to accelerate low-charge bunches to high energies. Thus, the complete RF system can be seen as an energy transformer which takes energy from high-charge, low-energy electron bunches and conveys it to low-charge, high-energy bunches of charged particles. When sufficient power cannot be obtained from a single amplifier then the output from several amplifiers may be combined. In some cases power is supplied to a number of accelerating cavities from one amplifier.



**Fig. 1:** Block diagram of the high-power RF system of an accelerator

Because the amplifier is never completely efficient there is always some conversion of energy into heat. The principle of conservation of energy requires that, in the steady state, the total input and output power must balance, that is

$$P_{RF\ in} + P_{DC\ in} = P_{RF\ out} + P_{Heat} \quad (1)$$

Strictly speaking, the input power should also include the power required for other purposes related to the amplifier including heaters, magnets and cooling systems. However, in many cases these are small compared with the RF output power and may be neglected to a first approximation. The efficiency ( $\eta_e$ ) of the amplifier is the ratio of the RF output power to the total input power

$$\eta_e = \frac{P_{RF\ out}}{P_{DC\ in} + P_{RF\ in}} \approx \frac{P_{RF\ out}}{P_{DC\ in}} \quad (2)$$

In many cases the RF input power is small compared with the d.c. input power so that it may be neglected to give the approximation shown in Eq. (2). The efficiency is usually expressed as a percentage. The heat which must be dissipated is

$$P_{Heat} = (1 - \eta_e) P_{DC} \quad (3)$$

The other main parameter of the generic amplifier is its gain in decibels given by

$$G = 10 \log_{10} \left( \frac{P_{RF\ out}}{P_{RF\ in}} \right) \quad (4)$$

The physics of the energy exchange between the electron bunches and the RF power means that the size of the space in which the exchange takes place must be small compared with the distance an electron moves in one RF cycle. Thus, the size of an amplifier decreases with decreasing d.c. voltage and with increasing frequency. Hence, for a given RF output power and efficiency, the energy density within the amplifier increases with decreasing size. The need to keep the working temperature of the amplifier below the level at which it will cease to operate reliably means that the maximum possible output power from a single device is determined by the working voltage, the frequency and the technology employed. Other factors which are important in the specification of power amplifiers include reliability and, in some cases, bandwidth.

The capital and running cost of an accelerator is strongly affected by the RF power amplifiers in a number of ways. The capital cost of the amplifiers (including replacement tubes) is an appreciable part of the total capital cost of the accelerator. Their efficiency determines the electricity required and, therefore, the running cost. The gain of the final power amplifier determines the number of stages required in the RF amplifier chain. The size and weight of the amplifiers determines the space required and can, therefore, have an influence on the size and cost of the tunnel in which the accelerator is installed.

All RF power amplifiers for high-power hadron accelerators employ vacuum tube technology. Vacuum tubes use d.c., or pulsed, voltages from several kilovolts to hundreds of megavolts depending upon the type of tube, the power level and the frequency. The electron velocities can be comparable with the velocity of light and the critical tube dimensions are therefore comparable with the free-space wavelength at the working frequency. Vacuum tubes can therefore generate RF power outputs up to 1 MW continuous wave (c.w.) and 150 MW pulsed. The types employed in high-power hadron accelerators are gridded tubes (triodes and tetrodes) and klystrons. Table 1 shows the parameters of the RF power amplifiers used in some existing or projected high-power hadron accelerators. In the future it is possible that inductive output tubes (IOTs) and magnetrons could be used for this purpose. The magnetron is an oscillator rather than an amplifier and its use is currently restricted to medical linacs. This paper reviews the state of the art of these types of amplifier and discusses some of the factors affecting their successful operation.

**Table 1a:** RF power amplifiers for c.w. hadron accelerators

<i>Lab</i>	<i>Accelerator</i>	<i>Type</i>	<i>RF source</i>	<i>Frequency</i> (MHz)	<i>Power (kW)</i>
RIKEN	RIBF SRC	Cyclotron	Tetrode	18 to 42	150
TRIUMF	TRIUMF	Cyclotron	Tetrode	23.06	125
PSI	PSI	Cyclotron	Tetrode	50	850
IFMIF	IFMIF	Linac	Diacrode	175	1000
CERN	SPS (Philips)	Synchrotron	Tetrode	200	35
CERN	SPS (Siemens)	Synchrotron	Tetrode	200	125
<b>CERN</b>	LHC	Synchrotron	Klystron	400	300


**Table 1b:** RF power amplifiers for pulsed hadron accelerators

<i>Laboratory</i>	<i>Accelerator</i>	<i>Type</i>	<i>RF Source</i>	<i>Frequency</i> (MHz)	<i>Power (MW pk)</i>	<i>Duty</i>
RAL	ISIS Synchrotron	Synchrotron	Tetrode	1.3 to 3.1	1	50 %
GSI	FAIR UNILAC	Linac	Tetrode	36	2	50 %
GIST	FAIR UNILAC	Linac	Tetrode	108	1.6	50 %
RAL	ISIS Linac	Linac	Triode	202.5	5	2 %
GSI	FAIR Linac	Linac	Klystron	325	2.5	0.08 %
ESS	ESS DTL	Linac	Klystron	352.2	1.3 and 2.5	5 %
ORNL	SNS RFQ & DTL	Linac	Klystron	402.5	2.5	8 %
ESS	ESS Elliptical	Linac	Klystron	704.4	2	4 %
<b>ORNL</b>	SNS CCL	Linac	Klystron	805	5	9 %

Solid state RF power transistors operate at voltages from tens to hundreds of volts. The electron mobility is much less in semiconductor materials than in vacuum and the device sizes are therefore small and the power which can be generated by a single transistor is of the order of hundreds of Watts continuous and up to 1 kW pulsed. Large numbers of transistors must be operated in parallel to reach even the lowest power levels required for accelerators. At the present time solid-state amplifiers are not able to meet the final power amplifier requirements for high-power hadron accelerators [2].

## 2 Tetrode amplifiers

Tetrode vacuum tubes are well established as high-power RF sources in the very-high-frequency (VHF; 30 MHz to 300 MHz) band. The arrangement of a 150 kW, 30 MHz, tetrode is shown in Fig. 2 (see also Ref. [3]). The construction is coaxial with the cathode inside and the anode outside. The output power available from such a tube is limited by the maximum current density available from the cathode and by the maximum power density which can be dissipated by the anode. The length of the anode must be much shorter than the free-space wavelength of the signal to be amplified to avoid variations in the signal level along it. The perimeter of the anode must likewise be much shorter than the free-space wavelength to avoid the excitation of azimuthal higher-order modes in the space between the anode and the screen grid. The spacings between the electrodes must be small enough for the transit time of an electron from the cathode to the anode to be much shorter than the RF period. If attempts are made to reduce the transit time by raising the anode voltage then there may be flashover between the electrodes. The bulk of the heat which must be dissipated arises from the residual kinetic energy of the electrons as they strike the anode. Thus, provision must be made for air or liquid cooling of the anode (see Section 7.1). Note the substantial copper anode with channels for liquid cooling shown in Fig. 2. For further information on gridded tubes, see Ref. [4].



**Fig. 2:** Cross-sectional view of a high-power tetrode (courtesy of e2v technologies)


The current of electrons emitted from the cathode surface is controlled by the field of the control grid modified by those of the other two electrodes. The dependence of the anode current on the electrode voltages is given approximately by

$$I_a \approx C \left( V_{g1} + \frac{V_{g2}}{\mu_2} + \frac{V_a}{\mu_a} \right)^n \quad (5)$$

where  $V_{g1}$ ,  $V_{g2}$  and  $V_a$  are, respectively, the potentials of the control grid, the screen grid and the anode with respect to the cathode and  $C$ ,  $\mu_1$ ,  $\mu_2$  and  $n$  are constants [5]. Typically  $\mu_2 \sim 5-10$ ,  $\mu_a \sim 100-200$  and  $n$  is in the range 1.5–2.5.

Figure 3 shows the characteristic curves of a typical tetrode [6]. The control grid voltage is plotted against the anode voltage, both being referred to the cathode. The three sets of curves show the anode current (solid lines), control grid current (dashed lines) and the screen grid current (chain dotted lines). The voltages of the anode (known as the plate in the USA) and the screen grid are positive with respect to the cathode. The curves shown are for a fixed screen grid voltage of +900 V. It is clear that the anode current depends strongly on the control grid voltage and more weakly on the anode voltage. The control grid voltage is normally negative with respect to the cathode to prevent electrons being collected on the grid with consequent problems of heat dissipation. The screen grid, which is maintained at RF ground, prevents capacitive feedback from the anode to the control grid. The screen grid voltage is typically about 10 % of the d.c. anode voltage. If the anode voltage falls below that of the screen grid then any secondary electrons liberated from the anode are collected by the screen grid.


Thus, when tetrodes are operated as power amplifiers the anode voltage is always greater than the screen grid voltage.



**Fig. 3:** Characteristic curves of the RS 2058 CJ tetrode for  $V_{g2} = 900 \text{ V}$  (courtesy of Siemens AG)

## 2.1 Tetrode amplifier circuits


Figure 4 shows the circuit of a grounded-grid tetrode amplifier with a tuned anode circuit. At low frequencies, a resistive anode load may be used but this is unsatisfactory in the VHF band and above because of the effects of parasitic capacitance. The amplifiers used in accelerators are operated at a single frequency at any one time so the limited bandwidth of the tuned anode circuit is not a problem. At the resonant frequency the load in the anode circuit comprises the shunt resistance of the resonator ( $R_S$ ) in parallel with the load resistance ( $R_L$ ). If the load impedance has a reactive component then it merely detunes the resonator and can easily be compensated for. The d.c. electrode potentials are maintained by the power supplies shown and the capacitors provide d.c. blocking and RF bypass.



**Fig. 4:** Circuit of a grounded-grid tetrode amplifier

## 2.2 Class B operation

The operation of tuned amplifiers is designated as class A, B or C according to the fraction of the RF cycle for which the tube is conducting. Amplifiers for accelerators are normally operated in, or close to, class B in which the tube conducts for half of each cycle. The d.c. bias on the control grid is set so that the anode current is just zero in the absence of a RF input signal. This ensures that the tube only conducts during the positive half-cycle of the RF input voltage and the conduction angle is  $180^\circ$ . Figure 5 illustrates the current and voltage waveforms, normalized to their d.c. values, under the simplifying assumptions that the behaviour of the tube is linear and that the anode load is tuned to resonance.



**Fig. 5:** Current and voltage waveforms in a tetrode amplifier operating in class B

If it is assumed that the tube is linear whilst it is conducting, the d.c. anode current is found by Fourier analysis of the current waveform in Fig. 5 to be

$$I_0 = \frac{I_{pk}}{\pi} = 0.318 \quad (6)$$

where  $I_{pk}$  is the peak current during the cycle. Similarly the RF anode current is given by

$$I_2 = 0.5 I_{pk} \quad (7)$$

In an ideal class B amplifier the minimum RF voltage is zero so that the relationship between the RF and d.c. anode voltages is

$$V_2 = V_0 \quad (8)$$

The d.c power is given by

$$P_0 = V_0 I_0 = \frac{V_0 I_{pk}}{\pi} \quad (9)$$

and the RF output power by

$$P_2 = \frac{1}{2} V_2 I_2 = \frac{1}{4} V_0 I_{pk} \quad (10)$$

The theoretical efficiency is then

$$\eta_e = \frac{P_2}{P_0} = \frac{\pi}{4} = 78.5\% \quad (11)$$

In practice the efficiency of a tetrode amplifier is less than the theoretical limit for two reasons. First, the non-linear relationship between the sinusoidal control-grid voltage and the anode current shown by Eq. (5) means that the constants in Eqs. (6) and (7) become 0.278 and 0.458 when  $n = 1.5$  and 0.229 and 0.397 when  $n = 2.5$ . Second, the need to ensure that the anode voltage always exceeds the screen grid voltage means that the amplitude of the RF anode voltage  $V_2$  is limited to around 90 % of  $V_0$ . Substitution of these revised figures into Eqs. (9)–(11) shows that the practical efficiency may be expected to lie in the range 74 % to 78 % depending on the value of  $n$ .

### 2.3 Class A, AB and C operation

The proportion of the RF cycle during which the tetrode is conducting can be adjusted by changing the d.c. bias voltage on the control grid. The operation then falls into one of a number of classes as shown in Table 2. If the negative grid bias is reduced then anode current flows when there is no RF drive. The application of a small RF drive voltage produces class A amplification in which the tube conducts throughout the RF cycle. As the RF drive voltage is increased the tube becomes cut off for part of the cycle and the operation is intermediate between class A and class B and known as class AB. When the grid bias is made more negative than that required for class B operation the tube conducts for less than half the RF cycle and the operation is described as class C. Analysis similar to that given above shows that the ratio of the RF anode current to the d.c. anode current increases as the conduction angle is reduced and, therefore, the efficiency increases. However, the amplitude of the RF drive voltage required to produce a given amplitude of the RF anode current increases as the conduction angle is reduced so that the gain of the amplifier decreases. Finally, the harmonic content of the RF anode current waveform increases as the conduction angle increases. The properties of the different classes of amplifier are summarized in Table 2. The amplifiers used for particle accelerators should ideally have high efficiency, high gain and low harmonic output. For this reason it is usual to operate them in class B or in class AB with a conduction angle close to 180°.

**Table 2:** Classes of amplifier

<i>Class</i>	<i>Conduction angle</i>	<i>Maximum theoretical efficiency</i>	<i>Negative grid bias increasing</i>	<i>Gain increasing</i>	<i>Harmonics increasing</i>
A	360°	50 %			
AB	180° to 360°	50 % to 78 %			
B	180°	78 %			
C	< 180°	78 % to 100 %			

## 2.4 Tetrode amplifier design

The performance of a tetrode amplifier is best explained by means of an example. This is based upon a 62 kW, 200 MHz amplifier used in the CERN SPS [7]. The amplifier uses a single RS2058CJ tetrode [6] operating with a d.c. anode voltage of 10 kV and 900 V screen grid bias.

The actual amplifier is operated in class AB but quite close to class B. For simplicity class B operation is assumed in the calculations which follow. The first stage is to estimate the probable efficiency of the amplifier. We assume that the minimum anode voltage is 1.5 kV. Scaling the figures given above which take account of the non-linearity of the tetrode suggests that the efficiency of the amplifier will lie in the range 70 % to 74 %. Let us assume that the efficiency is 72 %. This figure can be adjusted later, if necessary, when the actual efficiency has been calculated. Then the d.c. power input necessary to obtain the desired output power is

$$P_0 = 62 / 0.72 = 86 \text{ kW} \quad (12)$$

The d.c. anode voltage was chosen to be 10 kV so the mean anode current is

$$I_0 = 86 / 10 = 8.6 \text{ A} \quad (13)$$

The theoretical value of  $I_{pk}$  is given by Eq. (6) but when the non-linearity of the tetrode is taken into account it is found that this figure lies in the range 3.6–4.4 depending upon the value of  $n$ . If we take the factor to be 4.0 then

$$I_{pk} = 4.0 \times 8.6 = 34 \text{ A} \quad (14)$$

Next we construct the load line on the characteristic curves for the tube shown in Fig. 6 by joining the point 1.5 kV, 34 A to the quiescent point (10 kV, 0 A) We note that this requires the control grid voltage to swing slightly positive with a maximum of +70 V.




Fig. 6: Tetrode characteristic curves with load line (courtesy of Siemens AG)

The d.c. and RF currents are found by numerical Fourier analysis of the anode current waveform using values read from Fig. 7 at intervals of 15° with the results

$$I_0 = 8.9 \text{ A} \quad (15)$$

$$I_2 = 15.0 \text{ A} \quad (16)$$

Thus, the d.c. input power is

$$P_0 = I_0 V_0 = 89 \text{ kW} \quad (17)$$

The amplitude of the RF voltage is

$$V_2 = 10.0 - 1.5 = 8.5 \text{ kV} \quad (18)$$

and the RF output power is

$$P_2 = \frac{1}{2} V_2 I_2 = 64 \text{ kW} \quad (19)$$

which is very close to the desired value and gives an efficiency of 72 % as originally assumed. The effective load resistance is

$$R_L = V_2 / I_2 = 570 \Omega \quad (20)$$

The source impedance of the output of the amplifier can be found by noting that if the RF load resistance is zero the anode voltage is constant and the peak anode current is 46 A for the same RF voltage on the control grid. Thus, the short circuit RF current is 20 A and the anode source resistance ( $R_a$ ) is 1.7 kΩ.

To find the input impedance of the amplifier we note that the amplitude of the RF control grid voltage is

$$V_1 = 245 + 70 = 315 \text{ V} \quad (21)$$

and that for grounded grid operation the amplitude of the RF input current is

$$I_1 = I_2 + I_{g1RF} \approx I_2 \quad (22)$$

The amplitude of the RF control grid current ( $I_{g1RF}$ ) may be obtained by reading the control grid currents off Fig. 7 at 15° intervals and using numerical Fourier analysis. The result is 0.67 A which is small compared with the RF anode current and can be neglected in the first approximation. The RF input resistance is

$$R_1 = V_1 / I_1 = 20 \Omega \quad (23)$$

Finally we note that the input power is

$$P_1 = \frac{1}{2} V_1 I_1 = 2.5 \text{ kW} \quad (24)$$

and that the power gain of the amplifier is

$$\text{Gain} = 10 \log (64 / 2.5) = 14 \text{ dB} \quad (25)$$


Table 3 shows a comparison between the figures calculated above and those reported in Ref. [7]. The differences between the two columns of Table 4 are attributable to the difference between the actual class AB operation and the class B operation assumed in the calculations.

**Table 3:** Comparison between actual and calculated parameters of the amplifier described in Ref. [7]

<i>Parameter</i>	<i>Actual</i>	<i>Calculated</i>	
$V_0$	10	10	kV
$I_0$	9.4	8.9	A
$V_{g2}$	900	900	V
$V_{g1}$	-200	-245	V
$P_{out}$	62	64	kW
$P_{in}$	1.8	2.5	kW
Gain	15.4	14	dB
$\eta$	64	72	%

## 2.5 Practical details

Figure 7 shows a simplified diagram of a tetrode amplifier. The tube is operated in the grounded grid configuration with coaxial input and output circuits. The outer conductors of the coaxial lines are at ground potential and they are separated from the grids by d.c. blocking capacitors. The anode resonator is a re-entrant coaxial cavity which is separated from the anode by a d.c. blocking capacitor. The output power is coupled through an impedance matching device to a coaxial line. The anode HT connection and cooling water pipes are brought in through the centre of the resonator.




**Fig. 7:** Arrangement of a tetrode amplifier

The electrodes of the tube form coaxial lines with characteristic impedances of a few Ohms. We have seen above that the input impedance of the amplifier is typically a few tens of Ohms and the output impedance a few hundred Ohms. Thus, the terminations of both the input and output lines are close to open circuits. The anode resonator therefore has one end open circuited and the other short circuited and it must be an odd number of quarter wavelengths long at resonance. Typically the resonator is  $3/4$  of a wavelength long. In that case the point at which the output coaxial line is coupled into the resonator can be used to transform the impedance to provide a match.

## 2.6 Operation of tetrode amplifiers in parallel


When higher powers are required than can be obtained from a single tube then it is possible to operate several tubes in parallel. Two such systems are described in Ref. [8]. The original four 500 kW, 200 MHz power amplifiers for the CERN SPS each comprised four 125 kW tetrodes operating in parallel. Figure 8 shows the arrangement of one amplifier. The loads on the fourth arms of the 3 dB couplers normally receive no power. If one tube fails, however, they must be capable of absorbing the power from the unbalanced coupler. The amplifier also contains coaxial transfer switches (not shown in Fig. 8) which make it possible for a faulty tube to be completely removed from service. The remaining three tubes can then still deliver 310 kW to the load. A more recent design of 500 kW amplifier for the same accelerator employs sixteen 35 kW units operated in parallel with a seventeenth unit as the driver stage. Both types of amplifier operate at anode efficiencies greater than 55 % and overall efficiencies greater than 45 %.



**Fig. 8:** Arrangement for operation of tetrode amplifiers in parallel (courtesy of Siemens AG)

## 2.7 The Diacrode ®

A recent development of the tetrode is the Diacrode [9]. In this tube the coaxial line formed by the anode and the screen grid is extended to a short circuit as shown in Fig. 9. The consequence of this change is that the standing wave now has a voltage anti-node, and a current node, at the centre of the active region of the tube. The tetrode, in contrast has a voltage anti-node and current node just beyond the end of the active region, as shown in Fig. 9. Thus, for the same RF voltage difference between the anode and the screen grid, the Diacrode has a smaller reactive current flow and much smaller power dissipation in the screen grid than a tetrode of similar dimensions. This means that, compared with conventional tetrodes, Diacrodies can either double the output power at a given operating frequency or double the frequency for a given power output. The gain and efficiency of the Diacrode are the same as those of a conventional tetrode. Table 4 shows the comparison between the TH 526 tetrode and the TH 628 Diacrode operated at 200 MHz.




**Fig. 9:** Comparison between a tetrode and a Diacrode ® (courtesy of Thales Electron Devices)

**Table 4:** Comparison between the TH 526 tetrode and the TH 628 Diacrode at 200 MHz

<i>Tube</i>	<i>TH 526</i>		<i>TH 628</i>		
Pulse duration	2.2	c.w.	2.5	c.w.	ms
Peak output power	1600	–	3000	–	kW
Mean output power	240	300	600	1000	kW
Anode voltage	24	11.5	26	16	kV
Anode current	124	75	164	96	A
Peak input power	64.9	–	122.5	–	kW
Mean input power	–	21	–	32	kW
Gain	13.9	11.5	13.9	15	dB

### 3 Inductive output tubes


The tetrode suffers from the disadvantage that the same electrode, the anode, is part of both the d.c. and the RF circuits. The output power is, therefore, limited by screen grid and anode dissipation. In addition, the electron velocity is lowest when the current is greatest because of the voltage drop across the output resonator (see Fig. 5). To get high power at high frequencies it is necessary to employ high-velocity electrons and to have a large collection area for them. It is therefore desirable to separate the electron collector from the RF output circuit. The possibility that these two functions might be separated from each other was originally recognized by Haeff in 1939 but it was not until 1982 that a commercial version of this tube was described [10]. Haeff called his invention the 'inductive output tube' (IOT) but it is also commonly known by the proprietary name Klystrode ®.




**Fig. 10:** Arrangement of an IOT (©2010 IEEE, reproduced with permission)

Figure 10 shows a schematic diagram of an IOT [11]. The electron beam is formed by a gridded, convergent flow, electron gun and confined by an axial magnetic field (not shown). The gun is biased so that no current flows except during the positive half-cycle of the RF input. Thus, electron bunches are formed and accelerated through the constant potential difference between the cathode and the anode. The bunches pass through a cavity resonator as shown in Fig. 11 so that their azimuthal magnetic field induces a current in the cavity (hence, the name of the tube). Because the cavity is

tuned to the repetition frequency of the bunches, the RF electric field in the interaction gap is maximum in the retarding sense when the centre of a bunch is at the centre of the gap. The interaction between the bunches and the cavity resonator is similar to that in a class B amplifier. Figure 12 shows a plot of the positions of typical electrons against time. The slopes of the lines are proportional to the electron velocities and they show how kinetic energy is extracted from the electron bunches as they pass through the output gap (indicated by dashed lines). The RF power transferred to the cavity is equal to the kinetic power given up by the electrons. Because the electron velocity is high it is possible to use a much longer output gap than in a tetrode. The RF power passes into and out of the vacuum envelope through ceramic windows.



**Fig. 11:** Interaction between a bunched electron beam and a cavity resonator



**Fig. 12:** Electron trajectories in an IOT

The efficiency of an IOT can be estimated by noting that the relationship between the RF and d.c. currents in the beam is, approximately, from Eqs. (6) and (7)

$$I_1 = \frac{\pi}{2} I_0 \quad (26)$$

The effective voltage of the output gap is the product of the RF gap voltage and a transit time factor. The effective gap voltage cannot be greater than about 90 % of the voltage used to accelerate the electrons because the electrons leaving the gap must have sufficient residual velocity to enable them to leave the gap and pass into the collector. The maximum RF output power is therefore given by

$$P_2 = \frac{1}{2} I_1 V_{gap,eff} = \frac{0.9}{2} \cdot \frac{\pi}{2} \cdot I_0 V_0 = 0.71 P_0 \quad (27)$$

so that the maximum efficiency is approximately 70 %.

The advantages of the IOT are that it does not need a d.c. blocking capacitor in the RF output circuit because the cavity is at ground potential and that it has higher isolation between input and output and a longer life than an equivalent tetrode. These advantages are offset to some extent by the

need for a magnetic focusing field. The typical gain is greater than 20 dB and is appreciably higher than that of a tetrode; high enough in fact for a 60 kW tube to be fed by a solid-state driver stage. IOTs have been designed for ultra-high-frequency (UHF) TV applications. The IOTs designed for use in accelerators are operated in class B or class C. Further information about the IOT can be found in Refs. [10, 12, 13]. Table 5 shows the parameters of some IOTs designed for use in accelerators.


**Table 5:** Parameters of IOTs for use in accelerators

<i>Tube</i>	<i>2KDW250PA</i>	<i>VKP-9050</i>	<i>VKL-9130A</i>	
Manufacturer	CPI/Eimac	CPI	CPI	
Frequency	267	500	1300	MHz
Beam voltage	67	40	35	kV
Beam current	6.0	3.5	1.3	A
RF output power	280	90	30	kW
Efficiency	70	>65	>65	%
Gain	22	>22	>20	dB


## 4 Klystrons

At a frequency of 1.3 GHz the continuous output power of an IOT is limited to around 30 kW by the need to use a control grid to modulate the electron beam. At higher frequencies and high powers it is necessary to modulate the beam in some other way. In the klystron this is achieved by passing an unmodulated electron beam through a cavity resonator which is excited by an external RF source. The electrons are accelerated or retarded according to the phase at which they cross the resonator and the beam is then said to be velocity modulated. The beam leaving the gap has no current modulation but, downstream from the cavity, the faster electrons catch up the slower electrons so that bunches of charge are formed as shown in Fig. 13.

When an output cavity, tuned to the signal frequency, is placed in the region where the beam is bunched, the result is the simple two-cavity klystron illustrated in Fig. 14. RF power is induced in the second cavity in exactly the same way as in an IOT. This cavity presents a resistive impedance to the current induced in it by the electron beam so that the phase of the field across the gap is in anti-phase with the RF beam current. Electrons which cross the gap within  $\pm 90^\circ$  of the bunch centre are retarded and give up energy to the field of the cavity. Since more electrons cross the second gap during the retarding phase than the accelerating phase there is a net transfer of energy to the RF field of the cavity. Thus, the klystron operates as an amplifier by converting some of the d.c. energy input into RF energy in the output cavity.



**Fig. 13:** Applegate diagram showing the formation of bunches in a velocity modulated electron beam




**Fig. 14:** Arrangement of a two-cavity klystron

In practice, the gain and efficiency of a two-cavity klystron are too low to be of practical value. It is therefore usual to add further cavity resonators to increase the gain, efficiency and bandwidth of the tube. Figure 15 shows the arrangement of a multicavity klystron. The electron beam is formed by a diode electron gun for which

$$I_0 = K V_0^{1.5} \quad (28)$$

where  $K$  is a constant known as the perveance which, typically, has a value in the range  $0.5$  to  $2.0 \times 10^{-6} \text{ AV}^{-1.5}$ . The function of all of the cavities, except the last, is to form tight electron bunches from which RF power can be extracted by the output cavity. The first and last cavities are tuned to the centre frequency and have  $Q$  factors which are determined largely by the coupling to the input and output waveguides. The intermediate, or idler, cavities normally have high  $Q$  and are tuned to optimize the performance of the tube. The long electron beam is confined by an axial magnetic field to avoid interception of electrons on the walls of the drift tube. The spent electrons are collected by a collector in exactly the same way as in an IOT. The RF power passes into and out of the vacuum envelope through ceramic windows.



**Fig. 15:** Arrangement of a multicavity klystron

#### 4.1 Electron bunching in klystrons

The Applegate diagram in Fig. 13 ignores the effect of space-charge on the bunching. The space-charge forces oppose the bunching and, under small-signal conditions, the beam has current modulation but no velocity modulation at the plane of the bunch. As the beam drifts further the space-charge forces cause the bunches to disperse and reform periodically. From the point of view of an observer travelling with the mean electron velocity, the electrons would appear to be executing

oscillations about their mean positions at the electron plasma frequency. The plasma frequency is modified to some extent by the boundaries surrounding the beam and by the presence of the magnetic focusing field. The electron plasma frequency is given by

$$\omega_p = (\eta\rho/\epsilon_0)^{0.5} \quad (29)$$

where  $\eta$  is the charge to mass ratio of the electron and  $\rho$  is the charge density in the beam. The distance from the input gap to the first plane at which the bunching is maximum is then a quarter of a plasma wavelength ( $\lambda_p$ ) given by

$$\lambda_p = 2\pi u_0 / \omega_p \quad (30)$$

where  $u_0$  is the mean electron velocity. Theoretically the second cavity should be placed at a distance  $\lambda_p/4$  from the input gap so that the induced current in the second cavity is maximum. In practice, it is found that this would make a tube inconveniently long and the distance between the gaps is a compromise between the strength of interaction and the length of the tube.

The bunching length is independent of the input signal except at very high drive levels when it is found that it is reduced. If attempts are made to drive the tube still harder the electron trajectories cross over each other and the bunching is less. Figure 16 shows a typical Applegate diagram for a high-power klystron. It should be noted that, in comparison with the diagram in Fig. 13, the axes have been exchanged and uniform motion of the electrons at the initial velocity has been subtracted. The peak accelerating and retarding phases of the fields in the cavities are indicated by + and - signs. Those electrons which cross the input gap at an instant when the field is zero proceed without any change in their velocities and appear as horizontal straight lines. Retarded electrons move upwards and accelerated electrons move downwards in the diagram. Because the cavities are closely spaced space-charge effects are not seen until the final drift region.




Fig. 16: Applegate diagram for a high-efficiency klystron (courtesy of Thales Electron Devices)

The tube illustrated has five cavities. The bunching produced by the first cavity is imperceptible on the scale of this diagram but it is sufficient to excite the RF fields in the second cavity. The second cavity is tuned to a frequency which is above the signal frequency so that it presents an inductive impedance to the beam current. As a result the bunch centre coincides with the neutral phase of the field in the cavity and further velocity modulation is added to the beam which produces much stronger bunching at the third cavity. The third cavity is tuned to the second harmonic of the signal frequency as can be seen from a careful examination of the diagram. The principal purpose of this cavity is to cause the electrons which lie farthest from the bunch centre to be gathered into the bunch. The use of a second harmonic cavity increases the efficiency of a klystron by at least ten percentage points. The splitting of the lines in the diagram which occurs at this plane is caused by a divergence in the behaviour of electrons in different radial layers within the electron beam. The fourth cavity is similar to the second cavity and produces still tighter bunching of the electrons. By the time they reach the final cavity nearly all of the electrons are bunched into a phase range which is  $\pm 90^\circ$  with respect to the bunch centre. The output cavity is tuned to the signal frequency so that the electrons at the bunch centre experience the maximum retarding field and all electrons which lie within a phase range of  $\pm 90^\circ$  with respect to the bunch centre are also retarded. If the impedance of the output cavity is chosen correctly then a very large part of the kinetic energy of the bunched beam can be converted into RF energy. It should be noted that space-charge repulsion ensures that the majority of trajectories are nearly parallel to the axis at the plane of the output gap so that the kinetic energy of the bunch is close to that in the initial unmodulated beam.

## 4.2 Efficiency of klystrons

The output power of a klystron is given by

$$P_2 = \frac{1}{2} I_1 V_{eff} \quad (31)$$

where  $I_1$  is the first harmonic RF beam current at the output gap and  $V_{eff}$  is the effective output gap voltage. As in the case of the IOT the effective output gap voltage must be less than 90 % of  $V_0$  to ensure that the electrons have sufficient energy to leave the gap and enter the collector. In the IOT the peak current in the bunch cannot exceed the maximum instantaneous current available from the cathode and the maximum value of  $I_1$  is approximately equal to half the peak current. In the klystron, however, the d.c. beam current is equal to the maximum current available from the cathode and the bunches are formed by compressing the charge emitted in one RF cycle into a shorter period. In the theoretical limit the bunches become delta functions for which

$$I_1 = 2I_0 \quad (32)$$


Thus, the maximum possible value of  $I_1$  in a klystron is four times that in an IOT with the same electron gun. The factor is actually greater than this because the current available from the triode gun in an IOT is less than that from the equivalent diode gun in a klystron. In practice, the effects of space charge mean that the limit given by Eq. (32) is not attainable, but computer simulations have shown that the ratio  $I_1/I_0$  can be as high as 1.6 to 1.7 at the output cavity. Then, by substitution in Eq. (31), we find that efficiencies of up to 75 % should be possible.

It is to be expected that the maximum value of  $I_1/I_0$  will decrease as the space-charge density in the beam increases. An empirical formula for the dependence of efficiency on beam perveance derived from studies of existing high-efficiency klystrons is given in Ref. [14]:

$$\eta_e = 0.9 - 0.2 \times 10^{-6} K \quad (33)$$

If it is assumed that the limit  $K = 0$  corresponds to delta function bunches then it can be seen that Eq. (33) takes the maximum effective gap voltage to be  $0.9 V_0$ .


The maximum efficiency of klystrons decreases with increasing frequency because of increasing RF losses and of the design compromises which are necessary. This is illustrated by Fig. 17 which shows the efficiencies of c.w. klystrons taken from manufacturers' data sheets. It should be emphasized that the performance of most of these tubes will have been optimized for factors other than efficiency.



**Fig. 17:** Efficiencies of c.w. klystrons

### 4.3 Terminal characteristics of klystrons

The transfer characteristics of a klystron (Fig. 18) show that the device is a linear amplifier at low signal levels but that the output saturates at high signal levels. The performance of a klystron is appreciably affected by variations in the beam voltage, signal frequency and output match and we now examine these in turn.



**Fig. 18:** Klystron transfer characteristics

Klystrons for use in accelerators are normally operated close to saturation to obtain the highest possible efficiency. Figure 18 shows that the output power is then insensitive to variations of input power and, by extension, to variations of beam voltage. The effects on the phase of the output signal are more serious because of the distance from the input to the output.

The output power and efficiency of a klystron are affected by the match of the load which is normally a circulator. This is usually represented by plotting contours of constant load power on a Smith chart of normalised load admittance. Figure 19 shows such a chart, known as a Rieke diagram, for a typical klystron. Care must be taken to avoid the possibility of voltage breakdown in the output gap. If the gap voltage becomes too high it is also possible for electrons to be reflected so reducing the efficiency of the tube and providing a feedback path to the other cavities which may cause the tube to become unstable. The forbidden operating region is shown by shading on the diagram. A further complication is provided by the effect of harmonic signals in the output cavity. Since the klystron is operated in the non-linear regime to obtain maximum efficiency it follows that the signal in the output waveguide will have harmonic components. These are incompletely understood but it is known that the reflection of harmonic signals from external components such as a circulator can cause the klystron output to behave in unexpected ways.




Fig. 19: Rieke diagram for a klystron (courtesy of Thales Electron Devices)

#### 4.4 Typical super-power klystrons

Klystrons which have been developed specifically for use in accelerators are commonly known as super-power klystrons. Tables 6 and 7 summarize the state of the art for these tubes. The beam voltage is limited by the need to avoid voltage breakdown in the electron gun. It can be seen from the tables that the typical beam voltages are higher for pulsed tubes than for c.w. tubes because the breakdown voltage is higher for short pulses than for steady voltages. The beam current is limited by the current density which is available at the cathode and by the area of the cathode which decreases with frequency. The saturation current density of thermionic cathodes is greater for short (microsecond) pulses than for d.c. operation.

Table 6: Characteristics of typical c.w. super-power klystrons

<i>Tube</i>	<i>TH 2089</i>	<i>VKP-7952</i>	<i>TH 2103C<sup>a</sup></i>	
Manufacturer	Thales	CPI	Thales	
Frequency	352	700	3700	MHz
Beam voltage	100	95	73	kV
Beam current	20	21	22	A
RF output power	1.1	1.0	0.7	MW
Gain	40	40	50	dB
Efficiency	65	65	44	%

<sup>a</sup>This tube was developed for heating plasmas for nuclear fusion experiments

**Table 7:** Characteristics of typical pulsed super-power klystrons


<i>Tube</i>	<i>Ref.</i> <i>[15]</i>	<i>Ref.</i> <i>[16]</i>	<i>Ref.</i> <i>[17]</i>	
Frequency	2.87	3.0	11.4	GHz
Pulse length	1.0	1.0	1.6	$\mu$ s
Beam voltage	475	610	506	kV
Beam current	620	780	296	A
RF output power	150	213	75	MW
Gain	59	58	60	dB
Efficiency	51	44	50	%

#### 4.5 Multiple-beam klystrons

We have seen that the efficiency of a klystron is determined by the perveance of the electron beam so that, to get high efficiency, it is necessary to use a high-voltage, low-current beam. The use of high voltages produces problems with voltage breakdown and it is therefore difficult to obtain very high power with high efficiency. One solution to this problem is to use several electron beams within the same vacuum envelope as shown in Fig. 20. A klystron designed in this way is known as a multiple-beam klystron (MBK). The individual beams have low perveance to give high efficiency whilst the output power is determined by the total power in all of the beams. The principle of the MBK has been known for many years [18] but, until recently, the only such tubes constructed were in the former Soviet Union for military applications. The first MBK designed specifically for use in particle accelerators was the Thales type TH1801, the performance of which is shown in Table 8; see also Ref. [19].


**Table 8:** Characteristics of a MBK

<i>Type</i>	<i>TH 1801</i>	
Frequency	1300	MHz
Beam voltage	115	kV
Beam current	133	A
Number of beams	7	
Power	9.8	MW
Pulse length	1.5	ms
Efficiency	64	%
Gain	47	dB

**Fig. 20:** Arrangement of a multiple beam klystron (courtesy of Thales Electron Devices)

## 5 Magnetrons

The principle of operation of the magnetron is illustrated in Fig. 21. The tube has a concentric cylindrical geometry. Electrons emitted from the cathode are drawn towards the surrounding anode by the potential difference between the two electrodes. The tube is immersed in a longitudinal magnetic field which causes the electron trajectories to become cycloidal so that, in the absence of any RF fields, the diode is cut off, no current flows, and the electrons form a cylindrical space-charge layer around the cathode. The anode is not a smooth cylinder but carries a number of equally spaced vanes such that the spaces between them form resonant cavities. The anode supports a number of resonant modes with azimuthal RF electric field. The one used for the interaction is the  $\pi$  mode in which the fields in adjacent cavities are in anti-phase with one another. The RF fields in the anode are initially excited by electronic noise and there is a collective interaction between the fields and the electron cloud which causes some electrons to be retarded. These electrons move outwards forming 'spokes' of charge, the number of which is half the number of the cavities in the anode. The spokes rotate in synchronism with the RF field of the anode and grow until electrons reach the anode and current flows through the device. The electron velocities are almost constant during the interaction and the energy transferred to the RF field comes from their change in potential energy. The magnetron is an oscillator whose power output grows until it is limited by non-linearity in the interaction. RF power is extracted from the anode via a coupler and vacuum window.



**Fig. 21:** Arrangement of a magnetron oscillator

The magnetron is a compact device which is capable of achieving efficiencies of up to 90 % and it has been recognized for many years that it would be an attractive alternative to other tubes for powering particle accelerators. However, because it is a free-running oscillator, the frequency is not stable enough for use in most accelerators. The frequency of a magnetron varies with the current flowing through the tube (known as frequency pushing) and it is possible to use this to provide a degree of control. On its own this is not sufficient. It is also possible to lock the phase of a free-running oscillator by injecting RF power at the desired frequency. The power required increases with the difference between the natural frequency and the locked frequency and it is found that the power required to lock the phase of a magnetron is typically about 10 % of the output power of the tube. This power is unacceptably high. Recent work has shown that, when the frequency of a magnetron is first stabilized by a control loop using frequency pushing, it is then possible to lock the phase with an injected RF signal which is less than 0.1 % of the output power of the tube [20]. Thus, locked magnetrons may be used in the future for powering accelerators [21].

## 6 Limitations of vacuum tubes

The performance of high-power vacuum tubes is limited by a number of factors which operate in much the same way for all devices. The chief of these are heat dissipation, voltage breakdown, output window failure and multipactor discharges.

The dimensions of the RF structures and the windows of microwave tubes generally scale inversely with frequency. The maximum continuous, or average, power which can be handled by a particular type of tube depends upon the maximum temperature that the internal surfaces can be allowed to reach. This temperature is independent of the frequency so the power that can be dissipated per unit area is constant.

The power of a klystron or IOT is also limited by the power in the electron beam. The beam diameter scales inversely with frequency and the beam current density is determined by the maximum attainable magnetic focusing field. Since that field is independent of frequency the beam current scales inversely with the square of the frequency. The beam voltage is related to the current by the gun perveance which usually lies in the range 0.5 to 2.0 for power tubes. The maximum gun voltage is limited by the breakdown field in the gun and so varies inversely with frequency for constant perveance. These considerations suggest that the maximum power obtainable from a tube of a particular type varies as frequency to the power  $-2.5$  to  $-3.0$  depending upon the assumptions made. For pulsed tubes the peak power is limited by the considerations in this paragraph and the mean power by those in the preceding one.

The efficiencies of tubes tend to fall with increasing frequency. This is partly because the RF losses increase with frequency and partly because of the design compromises which must be made at higher frequencies.

The maximum power obtainable from a pulsed tube is often determined by the power-handling capability of the output window. Very-high-power klystrons commonly have two windows in parallel to handle the full output power. Windows can be destroyed by excessive reflected power, by arcs in the output waveguide, by X-ray bombardment and by the multipactor discharges described in the following paragraph. The basic cause of failure is overheating and it is usual to monitor the window temperature and to provide reverse power and waveguide and cavity arc detectors.

Multipactor is a resonant RF vacuum discharge which is sustained by secondary electron emission [22]. Consider a pair of parallel metal plates in vacuum with a sinusoidally varying voltage between them. If an electron is liberated from one of the plates at a suitable phase of the RF field it will be accelerated towards the other plate and may strike it and cause secondary electron emission. If the phase of the field at the moment of impact is just  $180^\circ$  from that at the time when the electron left the first plate, then the secondary electrons will be accelerated back towards the first plate. These conditions make it possible for a stable discharge to be set up if the secondary electron emission coefficients of the surfaces are greater than unity. It is found that phase focusing occurs so that electrons which are emitted over a range of phases tend to be bunched together. It is also possible for multipactor discharges to occur on ceramic surfaces with surface charge providing a static field. It should be noted that this type of discharge is not resonant and does not require the presence of a RF electric field. The local heating of a window ceramic in this way can be sufficient to cause window failure. Signs of multipactor are heating, changed RF performance, window failure and light and X-ray emissions. A multipactor discharge can sometimes be suppressed by changing the shape of the surfaces, by surface coatings, and by the imposition of static electric and magnetic fields.


## 7 Cooling and protection

### 7.1 Cooling power tubes

The power tubes used in accelerators typically have efficiencies between 40 % and 70 %. It follows that a proportion of the d.c. input power is dissipated as heat within the tube. The heat to be dissipated

is between 40 % and 150 % of the RF output power provided that the tube is never operated without RF drive. If a linear beam tube is operated without RF drive then the electron collector must be capable of dissipating the full d.c. beam power. The greater part of the heat is dissipated in the anode of a tetrode or in the collector of a linear-beam tube. These electrodes are normally cooled in one of three ways: by blown air (at low power levels), by pumped liquid (usually de-ionized water) or by vapour phase cooling. The last of these may be less familiar than the others and needs a little explanation.

The electrode to be cooled by vapour phase cooling is immersed in a bath of the liquid (normally de-ionized water) which is permitted to boil. The vapour produced is condensed in a heat exchanger which is either within the cooling tank (see Fig. 22) or part of an external circuit. The cooling system therefore forms a closed loop so that water purity is maintained. In all water cooling systems it is important to maintain the water purity to ensure that the electrodes cooled are neither contaminated nor corroded. Either of these effects can degrade the effectiveness of the cooling system and cause premature failure of the tube. In blown air systems careful filtering of the air is necessary for the same reasons.



**Fig. 22:** Vapour phase cooling of a tetrode (courtesy of e2v technologies)

It is important to remember that, in a high-power tube, appreciable quantities of heat may be dissipated on parts of the tube other than the anode or collector especially if a fault occurs during operation. It is common to provide air or water cooling for these regions also. Inadequate cooling may lead to the internal distortion or melting of the tube and its consequent destruction. Further information on the cooling of tubes is given in Refs. [23, 24].

## 7.2 Tube protection


Power tubes are very expensive devices and it is vital that they are properly protected when in use. The energy densities in the tubes and their power supplies are so high that it is easy for a tube to be destroyed if it is not properly protected. Nevertheless, with adequate protection tubes are in fact very good at withstanding accidental overloads and may be expected to give long, reliable, service.

Two kinds of protection are required. First a series of interlocks must be provided which ensures that the tube is switched on in the correct sequence. Thus, it must be impossible to apply the anode voltage until the cathode is at the correct working temperature and the cooling systems are functioning correctly. The exact switch-on sequence depends upon the tube type and reference must be made to the manufacturer's operating instructions. The sequence must also be maintained if the tube has to be restarted after tripping off for any reason.

The second provision is of a series of trips to ensure that power is removed from the tube in the event of a fault such as voltage breakdown or excessive reflected power. Again the range of parameters to be monitored and the speed with which action must be taken varies from tube to tube. Examples are: coolant flow rate; coolant temperature; tube vacuum; output waveguide reverse power; and electrode over-currents. If a tube has not been used for some time it is sometimes necessary to bring it up to full power gradually to avoid repeated trips. The manufacturer's operating instructions should be consulted about this. If a tube trips out repeatedly it is best to consult the manufacturer to avoid the risk of losing it completely by unwise action taken in ignorance of the possible causes of the trouble. General information about tube protection and safe operation is given in Refs. [23, 24].

## 8 Conclusion

This paper has provided an introduction to the main types of RF power source which are, or may be, used in high-power hadron accelerators. Figure 23 shows the state of the art in terms of mean or c.w. power output as a function of frequency for the RF power sources currently used in accelerators. Solid-state sources can compete with tubes at the lower frequencies and power levels and are likely to become more commonly used. The fall-off in power output at high frequencies for each type of tube is related to the fundamental principles of its operation as discussed in Section 6. The power achieved by klystrons at low frequencies does not generally represent a fundamental limitation but merely the maximum which has been demanded to date. For tetrodes and solid-state devices the maximum power is probably closer to the theoretical limits for those devices. In any case higher powers can be produced by parallel operation.



**Fig. 23:** State of the art of high-power RF sources

For further information on the theory of microwave tubes and for suggestions for background reading, see Refs. [24–26].

## References

- [1] R.G. Carter, *Contemp. Phys.* **52** (2011) 15–41.
- [2] R.G. Carter, R.F. power generation, Proc. of the CERN Accelerator School ‘RF for Accelerators’, Ebeltoft, Denmark, 8–17 June 2010 (CERN, Geneva, 2011).

- [3] CY1172 RF Power Tetrode Data Sheet, EEV Ltd, 1990.
- [4] K. Spangenburg, *Vacuum Tubes* (McGraw-Hill, New York, 1948).
- [5] A.H.W. Beck, *Thermionic Valves* (Cambridge University Press, Cambridge, 1953).
- [6] Siemens, *Transmitting Tubes Data Book 1986/87* (Siemens AG, 1986).
- [7] W. Herdrich and H.P. Kindermann, *IEEE Trans. Nucl. Sci.* **32** (1985) 2794–2796.
- [8] H. P. Kindermann, *et al.*, *IEEE Trans. Nucl. Sci.* **30** (1983) 3414–3416.
- [9] G. Clerc, *et al.*, A new generation of gridded tubes for higher power and higher frequencies, Proc. Particle Accelerator Conference, Vancouver, BC, 1997, pp. 2899–2901.
- [10] D. Preist and M. Shrader, *Proc. IEEE* **70** (1982) 1318–1325.
- [11] R.G. Carter, *IEEE Trans. Electron Dev.* **57** (2010) 720–725.
- [12] H. Bohlen, *et al.*, Inductive output tubes for particle accelerators, Presented at the EPAC 2004, Lucerne, Switzerland, 2004.
- [13] H. Bohlen, *et al.*, IOT RF power sources for pulsed and cw linacs, Presented at the LINAC 2004, Lübeck, Germany, 2004.
- [14] R.S. Symons, Scaling laws and power limits for klystrons, Proc. International Electron Devices Meeting, 1986, pp. 156–159.
- [15] T. Lee, *et al.*, *IEEE Trans. Plasma Sci.* **13** (1985) 545–552.
- [16] S. Choroba, *et al.*, Performance of an S-band klystron at an output power of 200MW, Proc. XIX International Linac Conference, Chicago, IL, USA, 1998, pp. 917–919.
- [17] D. Sprehn, *et al.*, Current status of the next linear collider X-band klystron development program, Proc. EPAC 2004, Lucerne, Switzerland, 2004, pp. 1090–1092.
- [18] M.R. Boyd, *et al.*, *IRE Trans. Electron Dev.* **9** (1962) 247–252.
- [19] A. Beunas and G. Faillon, 10 MW/1.5ms, L-band multi-beam klystron, Presented at the Displays and Vacuum Electronics Conference, Garmisch-Partenkirchen, Germany, 1998.
- [20] I. Tahir, *et al.*, *IEEE Trans. Electron Dev.* **52** (2005) 2096–2103.
- [21] R.G. Carter, Conceptual design of a 1MW 175MHz CW magnetron, Proc. IEEE International Vacuum Electronics Conference 2009 (IVEC '09), pp. 550–551.
- [22] J.R.M. Vaughan, *IEEE Trans. Electron Dev.* **35** (1988) 1172–1180.
- [23] EEV, Preamble - Tetrodes (EEV Ltd, 1976).
- [24] L. Sivan, *Microwave Tube Transmitters* (Kluwer Academic Publishers, Dordrecht, 1994).
- [25] R. J. Barker, *et al.*, *Modern Microwave and Millimetre-Wave Power Electronics* (IEEE, Piscataway, NJ, 2005).
- [26] J.A. Eichmeier and M. Thumm, Eds., *Vacuum Electronics: Components and Devices* (Springer, Berlin, 2008).